

Corner Cabinet Bi-Fold Door

Drilling Locations

Kitchen Concepts NSW

Notes:

- Four holes are required to be drilled when mounting the second door on corner cabinets. These are shown in red on this diagram.
- Holes drilled are to be 5mm in diameter and 12mm deep.
- Use a depth gauge or other marking or stopping tool, to ensure drill does not penetrate painted surface
- Place door face down on a soft surface (e.g. packing foam) when drilling to ensure the door is not marked.

